

1. Press ∇ * #
 2. The LCD will read SOS1.
 3. Use the ∇ key to scroll down to OTHER FUNCTIONS.
 4. Press OK.
 5. You will now see SOS 9 and 10.
 6. Scroll down to SOS10 and press OK.
 7. The display will read 00011010.
 8. Using the numeric keypad, key in the following sequence: 00011000
 9. Press OK.
 10. Press C x2. The display should read PLEASE WAIT while the changes are stored.
 11. After doing this press ∇ 2512.
 12. You should then select PULSE dialling.
 13. Press OK
 14. Press C x4 and again the display should read PLEASE WAIT.
-